

Bracket Installation Options



The **BHP76 Button Head Bolt** is used to secure our Supr-Lok™ and Ultra Supr-Lok™ brackets to a u-channel sign post when used as part of a vandal-resistant or *bolt-through* installation.



The **PRP38 Vandal-Resistant Set Screw** is used to secure Supr-Lok™ and Ultra Supr-Lok™ brackets to a round post *or* to secure street name signs in our Supr-Lok™ and Ultra Supr-Lok™ brackets for a vandal-resistant installation.



The **VPA12 Vandal-Resistant Bolt** is used to secure street name signs in our Supr-Lok™ and Ultra Supr-Lok™ brackets for a *bolt-through* installation.



#12U-180F Ultra Supr-Lok™ Cap
#12U-180X Ultra Supr-Lok™ Cap

Standard Kit:

- (2) 5/16" x 5/8" Hex Bolts
- (3) SK56 Set Screws

Vandal-Resistant Kit:

- (2) BHP76 Vandal-Resistant Bolts
- (3) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.



#12U-90F Ultra Supr-Lok™ Cap
#12U-90X Ultra Supr-Lok™ Cap

Standard Kit:

- (2) 5/16" x 5/8" Hex Bolts
- (3) SK56 Set Screws

Vandal-Resistant Kit:

- (2) BHP76 Vandal-Resistant Bolts
- (3) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.



#1238F Ultra Supr-Lok™ Cap
#1238X Ultra Supr-Lok™ Cap

Standard Kit:

- (7) SK56 Set Screws

Vandal-Resistant Kit:

- (7) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace **three** of the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.



#12-CRF Ultra Supr-Lok™ Cap
#12-CRX Ultra Supr-Lok™ Cap

Standard Kit:

- (6) SK56 Set Screws

Vandal-Resistant Kit:

- (6) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.

Bracket Installation Options



The **5/16" x 5/8" Hex Bolt** is used to secure our Supr-Lok™ and Ultra Supr-Lok™ brackets to a u-channel sign post when used as part of a standard installation.



The **SK56 Set Screw** is used to secure our Supr-Lok™ and Ultra Supr-Lok™ brackets to a round post or to secure street name signs in our Supr-Lok™ and Ultra Supr-Lok™ brackets for a standard installation.



The **F100 Allen Wrench** tool is included with all brackets orders for installation of our SK56 and PRP38 set screws and BHP76 bolts. The T43 tool (not pictured) is used with the VPA12 bolts.



#91UF-NU180 Supr-Lok™ Cap
#91UX-NU180 Supr-Lok™ Cap

Standard Kit:

- (2) 5/16" x 5/8" Hex Bolts
- (2) SK56 Set Screws

Vandal-Resistant Kit:

- (2) BHP76 Vandal-Resistant Bolts
- (2) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.



#91UF-OL90 Supr-Lok™ Cap
#91UX-OL90 Supr-Lok™ Cap

Standard Kit:

- (2) 5/16" x 5/8" Hex Bolts
- (2) SK56 Set Screws

Vandal-Resistant Kit:

- (2) BHP76 Vandal-Resistant Bolts
- (2) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.



#922F Supr-Lok™ Cap
#922X Supr-Lok™ Cap

Standard Kit:

- (6) SK56 Set Screws

Vandal-Resistant Kit:

- (6) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace **two** of the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.



#990F Supr-Lok™ Cap
#990X Supr-Lok™ Cap

Standard Kit:

- (4) SK56 Set Screws

Vandal-Resistant Kit:

- (4) PRP38 Vandal-Resistant Set Screws

For a **Bolt-Through Installation**, replace the SK56 or PRP38 Set Screws with **VPA12 Vandal-Resistant Bolts**.